


Installation guide

ARENA 4 (25x12m)

Code: BO-AR-004



INTER-PLAY


tel. +48 91 506 50 41, export@inter-play.eu, www.inter-play.eu

NR

ELEMENT


Code: BO-AR-004

E1




2

E2




2

E3




2

E4




2

E5









2

E6



2


NR	ELEMENT	Code: BO-AR-004
E7		4
E8		16
E9		4
E10		2
E11		4
E12		4

NR

ELEMENT


Code: BO-AR-004

E13




2

E14




4

E15




34

E16




2

E17



12

E18




8

NR

ELEMENT


Code: BO-AR-004

E19




2

E20




8

E21




2

E22




4

E23






2


E24





2

NR	ELEMENT	Code: BO-AR-004
E25		2
E26		2
E27		1



Code: BO-AR-004



Code: BO-AR-004





Code: BO-AR-004




Code: BO-AR-004

54x




1







2



Column codes directed outside the ARENA.




3




4



Code: BO-AR-004



B25 2,2m³



min. 48H

